


**SERIES 70**

**SERVO NXT - ETHERNET/IP**

Installation, Operation and Maintenance Manual



FOR MORE INFORMATION ON THIS PRODUCT AND OTHER BRAY PRODUCTS  
PLEASE VISIT OUR WEBSITE – [www.bray.com](http://www.bray.com)

## Table of Contents

1.0 Safety Instructions - Definition of Terms . . . . .	3
2.0 Introduction. . . . .	3
2.1 Definition of Terms . . . . .	3
3.0 Description of Operation . . . . .	3
3.1 Operational Modes . . . . .	4
3.1.1 Remote Mode . . . . .	4
3.1.2 Local Mode . . . . .	4
3.1.3 Manual Mode . . . . .	4
3.1.4 Autocalibration Mode . . . . .	4
4.0 Hardware Description . . . . .	5
4.1 EtherNet/IP Connections . . . . .	5
4.1.1 EtherNet/IP Connector . . . . .	5
4.2 Power Connections . . . . .	6
4.2.1 Input Power . . . . .	6
4.2.2 Heater (optional). . . . .	6
4.2.3 Motor . . . . .	6
4.3 Factory Connections . . . . .	6
4.3.1 Limit Switches . . . . .	6
4.3.2 Torque Switches (optional). . . . .	6
4.3.3 Handwheel Switch. . . . .	6
4.3.4 Control Box (optional) . . . . .	7
4.3.5 Potentiometer . . . . .	7
4.4 LED Description. . . . .	8
4.4.1 Ethernet Link . . . . .	8
4.4.2 EtherNet Speed . . . . .	9
4.4.3 Module Status . . . . .	9
4.4.5 Position . . . . .	9
4.4.6 Product Status . . . . .	9
4.4.7 Fault Indicators . . . . .	9
4.4.7.1 Limit Switch Fault . . . . .	9
4.4.7.2 Handwheel Fault . . . . .	9
4.4.7.3 Torque Fault. . . . .	9
4.4.7.4 Feedback Fault . . . . .	9
4.4.8 Autocalibration . . . . .	9
4.4.9 Manual Mode . . . . .	9
4.5 User Switches . . . . .	9
4.5.1 Autocalibration Switch. . . . .	9
4.5.2 Manual Mode Switch . . . . .	10

4.5.3 Up Arrow Switch . . . . .	10
4.5.4 Down arrow Switch . . . . .	10
4.5.5 Enter Switch . . . . .	10
5.0 EtherNet/IP Interface . . . . .	10
5.1 EtherNet/IP Conformance. . . . .	10
5.2 Scanner Configuration . . . . .	10
5.3 Address Assignment . . . . .	10
5.4 Establish Connection . . . . .	11
5.4.1 Input Assembly Data. . . . .	12
5.4.2 Output Assembly Data. . . . .	15
5.4.3 Configuration Assembly Data . . . . .	16
6.0 Quick Start Guide . . . . .	18
7.0 Technical Specifications . . . . .	19

## 1.0 Safety Instructions - Definition of Terms

**READ AND FOLLOW THESE INSTRUCTIONS  
SAVE THESE INSTRUCTIONS**



**WARNING**

Indicates a potentially hazardous situation which, if not avoided, **could** result in death or serious injury.



**CAUTION**

Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.

**NOTICE**

Used without the safety alert symbol indicates a potential situation which, if not avoided, may result in an undesirable result or state, including property damage.

## 2.0 Introduction

The S70 Servo NXT EtherNet/IP controller is an EtherNet/IP adapter that provides complete control and monitoring of the Bray S70 Electric Valve Actuator. The basic function of the S70 Servo NXT EtherNet/IP is to position the S70 Actuator in response to commands from an EtherNet/IP scanner. The scanner generates the desired process setpoint, in this case valve position, and continually monitors the process variables generated by the adapters. Varying commands to the S70 Servo NXT EtherNet/IP will change the S70 Actuator position, which in turn moves the underlying control valve to create a change in the process variable. The scanner calculates and transmits the appropriate commands to the S70 Servo NXT EtherNet/IP to establish and maintain the desired process setpoint.

### 2.1 Definition of Terms

- Servo NXT EIP – Bray EtherNet/IP-based controller, primarily intended for use in the Series 70 electric actuator. It is assumed that any actuator is connected to a rotary valve.
- Scanner – Opens connections with EtherNet/IP adapters, like the Servo NXT EIP, and initiates data transfers.

## 3.0 Description of Operation

The primary function of the Servo NXT EIP is to position the valve based on the feedback position provided by a local potentiometer. The feedback position is internally correlated to the valve position through an autocalibration sequence, where the Servo NXT EIP finds the limits of operation by operating the actuator through its range of travel. Once calibrated, the Servo NXT EIP will operate the actuator until the feedback position is close enough to the command position that it is within the deadband, aka the maximum allowed offset in positioning of the valve. The command position is provided by the scanner and ultimately determines the valve position.

The Servo NXT EIP is a product that conforms to the requirements set forth in the EtherNet/IP standards, an industrial EtherNet network solution defined by the ODVA. This ensures the Servo NXT EIP operates reliably when connected to other conformant EtherNet/IP devices. Additionally, the Servo NXT EIP uses the same communication objects as other EtherNet/IP devices, making for a consistent experience during setup and use.

## 3.1 Operational Modes

### 3.1.1 Remote Mode

By default, the operating mode of the Servo NXT EIP is Remote Mode, where the valve is positioned based on commands from the EtherNet/IP network. Exiting another mode of operation generally results in the Servo NXT EIP returning to remote mode.

### 3.1.2 Local Mode

Local Mode is entered if a connection is made to the Control Box terminals and one or both terminal voltages are pulled low. This allows the Servo NXT EIP to be controlled by a local control box, mounted to or near the actuator.

This mode of operation prevents remote operation of the Servo NXT EIP. Once exiting Local Mode, the unit will return to Remote Mode.

### 3.1.3 Manual Mode

This operating mode allows for the actuator to be controlled directly from the buttons on the Servo NXT EIP. By utilizing the keypad, the user can change the position of the valve with a single button press.

Manual mode is exited in the same way it is entered: by pressing and holding the manual mode button for 1 second. While in manual mode, the indicator next to the manual mode button remains lit. Manual mode can only be entered when the unit is in Remote Mode.

This mode allows the unit to be positioned using the buttons on the Servo NXT EIP.

- Up arrow button – energizes actuator in the open direction
- Down arrow button – energizes actuator in the close direction
- Enter button – brakes the actuator if it is operating

This mode of operation prevents remote operation of the Servo NXT EIP. Once exiting Manual Mode, the unit will return to Remote Mode.

### 3.1.4 Autocalibration Mode

The Servo NXT EIP uses an automated calibration sequence to determine the operating points for the application in which it is installed. These operating points allow the Servo NXT EIP to calculate the correct feedback position of the product, making autocalibration an important step during commissioning.

Servo NXT EIP units that have not been calibrated will flash the indicator next to autocalibration button to show that they are using default values for calculating position. Autocalibration Mode is entered by pressing and holding the Autocalibration button for at least 3 seconds. While in Autocalibration Mode, the autocalibration indicator remains lit. Upon completion of the autocalibration sequence, the autocalibration indicator will no longer flash and remain off, indicating that the new parameters have been stored in memory.

If a fault occurs during autocalibration, then the autocalibration sequence is aborted and all the fault LEDs will start flashing to indicate a failed autocalibration attempt. The unit will not operate while this fault is active. To clear the fault, the handwheel can be pulled out to indicate operator interaction. Additionally, there is also an output bit that can be toggled to clear the fault.

No other operating modes can be entered during autocalibration and entering Autocalibration Mode will override any previous mode of operation. This mode of operation prevents remote operation of the Servo NXT EIP. Once exiting Autocalibration Mode, the unit will return to Remote Mode.

## 4.0 Hardware Description

- One terminal strip (4 terminals) for EtherNet/IP connections
  - Used to land the EtherNet/IP field connector leads
- One terminal strip (7 terminals) for power connections
  - 2 terminals for input power (120VAC, 230VAC, 24VAC, or 24VDC)
  - 2 terminals for the internal heater (optional)
  - 2 terminals for motor connections (24VAC or 24VDC)
  - 3 terminals for motor connections (120VAC or 230VAC)
- One terminal strip (16 terminals) for factory wiring
  - 4 terminals limit switches
  - 4 terminals torque switches
  - 2 terminals handwheel switch
  - 3 terminals control box connections
  - 3 terminals potentiometer
- LED User Interface
  - Yellow Ethernet Link LED
  - Green Ethernet Speed LED
  - Bi-color (red / green) CIP Module Status LED
  - Bi-color (red / green) CIP Network Status LED
  - Bi-color (red / green) Position LED
  - Red Status LEDs
    - Illuminate the Bray logo
  - Red Fault LEDs
    - Limit Switch fault
    - Handwheel fault
    - Torque fault
    - Feedback fault
  - White Autocalibration LED
  - White Manual Mode LED


- User switches
  - Autocalibration switch
  - Manual Mode switch
  - Up arrow switch
  - Down arrow switch
  - Enter switch

### 4.1 EtherNet/IP Connections

The Servo NXT EIP has 4 terminals dedicated to EtherNet/IP physical layer connections, 1 pair for data transmission (TX+ & TX-) and 1 pair for data reception (RX+ & RX-). These terminals are treated as pairs since the signal wires in the CAT cables are twisted pairs.

#### 4.1.1 EtherNet/IP Connector

Actuators with the Servo NXT EIP installed will have the option for installation of a field connector for easy termination of EtherNet/IP network cabling at the unit. The connector is a male 4-pin "D" coded M12 connector as defined in Amendment 1 of IEC 61076-2-101. Since it is a male connector, a cable with a matching female M12 end is required for mating. See required cable pinout below.



- 1 = WHITE/ORANGE (+TX)
- 2 = WHITE/GREEN (+RX)
- 3 = ORANGE (-TX)
- 4 = GREEN (-RX)

**Figure 1:** EtherNet/IP cable pinout required for connection to Servo NXT EIP M12 connector

## 4.2 Power Connections

### 4.2.1 Input Power

Due to the power requirements of large electric actuators, the Servo NXT EIP has a dedicated power input separate from the EtherNet/IP network cabling. This power input energizes not only the Servo NXT EIP, but also the actuator motor used to position the valve.

Power provided to the Servo NXT EIP should be within 10% of the voltage listed for the actuator. For example, a 24VAC actuator should have power provided that has a voltage within 21.6 and 26.4VAC after voltage drops of the cabling. Additionally, the power supply should be capable of sourcing 5A per actuator, since the actuator is capable of drawing large currents on startup.

**Note:** 24VAC actuators should have a dedicated 100VA transformer for each actuator

### 4.2.2 Heater (optional)

The S70 has the option of having a cartridge heater installed at the factory. These 2 terminals provide a connection point for this heater, providing fused power to the heater from the input power terminals.

### 4.2.3 Motor

The S70 actuator is driven by either a split capacitor induction motor (120VAC or 230VAC operation) or a brushed DC motor (24VAC or 24VDC operation). The Servo NXT EIP provides power to the motor to operate the actuator and position the valve based on the command position provided by the scanner.

## 4.3 Factory Connections

One large terminal strip is provided on the Servo NXT EIP for connections switches and potentiometer internal to the actuator. These connections are generally made at the factory and should not require adjustment in the field.

### 4.3.1 Limit Switches

The switches attached to this terminal strip have been set at the factory to be engaged when the limits of travel have been reached, in other words, when the fully open and fully close positions have been reached. These switches prevent the Servo NXT EIP from operating the actuator to a point where the gearing could bind up and become damaged. These switches are engaged by a cam shaft coupled to the

output gear of the actuator, and the cams on the cam shaft should be adjusted to ensure the limit switches are engaged before any other mechanical limits are reached.

The Servo NXT EIP provides a logic level voltage at the Open (LO) and Close (LC) terminals of this connection. Once one of the travel limit switches is engaged, the switch at the applicable connection will engage and pull this pin to 0V, signaling the Servo NXT EIP to end operation.

For proper operation, both travel limit switches should not be engaged at the same time. This would prevent the Servo NXT EIP from operating the actuator, and results in a limit switch fault.

### 4.3.2 Torque Switches (optional)

If the torque present on the output of the actuator goes outside the rated torque listed for the unit, then the actuator gearing could be damaged. These switches detect the presence of high torque on the output gear, and if activated, put the Servo NXT EIP into a fault state. This fault state prevents further operation until the torque is reduced.

The Servo NXT provides a logic level voltage at the Open (TO) and Close (TC) terminals of this connection. If the actuator torque increases above the rated torque, the switch at the applicable connection will pull this pin to 0V, signaling the Servo NXT to enter a torque switch fault.

### 4.3.3 Handwheel Switch

The S70 actuator comes with an external handwheel that can be pulled out to allow for the valve to be positioned manually. If the handwheel is pulled out or engaged, then a switch is activated in the actuator, putting the Servo NXT EIP into a fault state. This fault state is active until the handwheel is pushed back in or disengaged.

The Servo NXT EIP provides a logic level voltage at the HW terminal of this connection. If the handwheel is engaged (pulled out), this pin will get pulled to 0V, signaling the Servo NXT EIP and resulting in a handwheel fault.



#### 4.3.4 Control Box (optional)

Connections for the local control station, if present. The local control station allows for local operation of the actuator, putting the Servo NXT EIP into Local Mode and overriding remote input commands.

The Servo NXT EIP provides a logic level voltage at the Open (BO) and Close (BC) terminals of this connection. If a switch connects either of the terminals to the COM terminal, this pin will be pulled to 0V, signaling the Servo NXT EIP to enter Local Mode. The Servo NXT EIP will not exit Local Mode until the Open and Close terminals return to their original voltage level. Once in Local Mode, the Servo NXT will ignore input commands until remote operation resumes

#### 4.3.5 Potentiometer

In addition to the limit switches, a potentiometer is also coupled to the cam shaft, this time by a set of gears. This potentiometer provides an analog voltage to the Servo NXT EIP that can be correlated to the position of the output gear of the actuator. This voltage ranges between 0-3.3VDC. To prevent damage to the potentiometer, any voltage value below 0.1VDC and greater than 3.2VDC is considered outside of the range of the potentiometer and puts the Servo NXT EIP into a feedback potentiometer fault. This fault state prevents further operation until the actuator is positioned so the potentiometer is back within its valid range.

**Table 1 - Module Status States**

(from Section 9-4.2.3 of The CIP Networks Library, Volume 2, EtherNet/IP Adaptation of CIP, Ed. 1.26, April 2020)

Indicator State:	Summary	Requirement
Steady Off	No Power	If no power is supplied to the device, the module status indicator shall be steady off.
Steady Green	Device Operational	If the device is operating correctly, the module status indicator shall be steady green
Flashing Green	Standby	If the device has not been configured, the module status indicator shall be flashing green.
Flashing Red	Major Recoverable Fault	If the device has detected a Major Recoverable Fault the module status indicator shall be flashing red.  NOTE: An incorrect or inconsistent configuration would be considered a Major Recoverable Fault
Steady Red	Major Unrecoverable Fault	If the device has detected a Major Unrecoverable Fault, the module status indicator shall be steady red.
Flashing Green/Red	Self-Test	While the device is performing its power up testing, the module status indicator shall perform the test sequence as described in Section 9-4.1.4

## 4.4 LED Description

### 4.4.1 Ethernet Link

This yellow LED indicates the status of the Servo NXT EIP ethernet link. If it is on, then the link is good, and communication can occur. In addition, this LED also shows link activity. It blinks whenever an ethernet packet is transmitted or received.

**Table 2: Network Status Indicator**

(from Section 9-4.3.3 of The CIP Networks Library, Volume 2, EtherNet/IP Adaptation of CIP, Ed. 1.26, Apr 2020)

Indicator State:	Summary	Requirement
Steady Off	Not Powered No IP Address	The device is powered off, or is powered on but with no IP address configured (Interface Configuration attribute of the TCP/IP Interface Object).
Flashing Green	No Connection	An IP address is configured, but no CIP connections are established, and an Exclusive Owner connection has not timed out.
Steady Green	Connected	An IP address is configured, at least one CIP connection (any transport class) is established, and an Exclusive Owner connection (defined in Volume 1, Chapter 3) has not timed out.
Flashing Red	Connection Timeout	An IP address is configured, and an Exclusive Owner connection (defined in Volume 1, Chapter 3) for which this device is the target has timed out. The network status indicator shall return to steady green only when all timed out Exclusive Owner connections are reestablished.  Devices that support a single Exclusive Owner connection shall transition to steady green when any subsequent Exclusive Owner connection is established.  Devices that support multiple Exclusive Owner connections shall retain the O->T connection path information when an Exclusive Owner connection times out. The network status indicator shall transition from flashing red to steady green only when all connections to the previously timed-out O->T connection points are reestablished.  Timeout of connections other than Exclusive Owner connections shall not cause the indicator to flash red.  The Flashing Red state applies to target connections only. Originators and CIP Routers shall not enter this state when an originated or routed CIP connection times out.
Steady Red	Duplicate IP	For devices that support duplicate IP address detection, the device has detected that (at least one of) its IP address is already in use.
Flashing Green/Red	Self-Test	While the device is performing its power up testing, the network status indicator shall perform a test sequence as described in Section 9-4.1.4

**Note:** when a single indicator is used to represent multiple IP address interfaces the state of any one interface shall be sufficient to modify the indicator state (per the above behavior in the table).

- Transition to flashing green when any one interface receives an IP address
- Transition to steady green when a CIP connection is established on any interface (and Exclusive owner is not timed out).
- Transition to flashing red when an Exclusive Owner CIP connection times out on any interface.
- Transition to steady red when any of the interfaces detects an IP address conflict.

#### 4.4.2 EtherNet Speed

This green LED indicates the communication speed of the Servo NXT EIP. If it is on, the unit is configured to communicate at 100Mb/s. If it is off, it is configured to communicate at 10Mb/s.

#### 4.4.3 Module Status

This bi-color (green, red) LED provides device status. It indicates whether the device has power and is operating properly.

#### 4.4.4 Network Status

This bi-color (green, red) LED displays EtherNet/IP configuration information for the Servo NXT EIP.

#### 4.4.5 Position

This bi-color (green, red) LED displays the position of the valve. If the valve is fully open and the open limit switch is engaged, the green LED is on and solid. If the actuator is operating in the open direction, the green LED will be flashing. If the valve is fully closed and the close limit switch is engaged, the red LED is on and solid. If the actuator is operating towards the close position, the red LED will be flashing. The LED will be dark if the unit is not operating and it is not positioned at the travel limits.

#### 4.4.6 Product Status

These 2 red LEDs, illuminating the Bray logo, flash periodically to indicate the unit is powered and operational. If these LEDs are not on, then the unit likely does not have power applied. If these LEDs are solid, then the unit should be power cycled to clear any potential internal faults.

#### 4.4.7 Fault Indicators

##### 4.4.7.1 Limit Switch Fault

This red LED is on if a limit switch fault is active. This occurs if the Servo NXT EIP detects that both limit switches are engaged. Since these switches are normally closed and electrically open when engaged, this can occur if the switches become disconnected from the terminals. Additionally, if one switch is engaged and the other switch has a wire disconnected, then this fault will also occur.

##### 4.4.7.2 Handwheel Fault

This red LED is on if a handwheel fault is active. This occurs if the handwheel is detected to be in use by an operator. If the handwheel is engaged

or pulled out, a switch connected to the Servo NXT EIP is engaged and signals that motor operation needs to be cease. The Servo NXT EIP will remain inactive while the handwheel is engaged.

##### 4.4.7.3 Torque Fault

This red LED is on if a torque switch fault is active. This occurs if one or both torque limit switches are engaged. While these switches are engaged, the unit will not operate until the high torque event has been cleared.

##### 4.4.7.4 Feedback Fault

This red LED is on if a feedback fault is active. This occurs if the feedback potentiometer is operated outside of its region of safe operation. Since the potentiometer is not a 360° model, it has internal mechanical limits that cannot be exceeded without damaging the unit. This fault state prevents the potentiometer from being operated beyond its physical limitations.

#### 4.4.8 Autocalibration

This white LED is on when Autocalibration Mode is active.

This mode of operation prevents remote operation of the Servo NXT EIP. Once exiting Autocalibration Mode, the unit will return to Remote Mode.

#### 4.4.9 Manual Mode

This white LED is on when the unit is operating in Manual Mode.

This mode of operation prevents remote operation of the Servo NXT EIP. Once exiting Manual Mode, the unit will return to Remote Mode.

### 4.5 User Switches

#### 4.5.1 Autocalibration Switch

Switch that engages and disengages the Autocalibration sequence for the Servo NXT EIP.

To enter autocalibration, the switch should be pressed and held for > 1 second. Once the switch is released, the autocalibration LED will turn on, indicating that the autocalibration state is active.

Pressing and holding the switch while autocalibration is active will cause the autocalibration state to be immediately exited

without completing, and the autocalibration LED will turn off.

### 4.5.2 Manual Mode Switch

Switch that engages and disengages Manual Mode for the Servo NXT EIP.

If the unit is in remote mode, pressing and holding the switch for > 1 second will cause the unit to enter Manual Mode once the switch is released. The Manual Mode LED will turn on to indicate the new operational state.

To exit Manual Mode, press and hold the switch for >1 second. Upon release, the Manual Mode LED will turn off and the unit will return to remote mode.

### 4.5.3 Up Arrow Switch

Used to operate the actuator while in Manual Mode. Pressing on this switch while in Manual Mode operates the actuator in the open direction. Switch has no function outside of manual mode.

### 4.5.4 Down arrow Switch

Used to operate the actuator while in Manual Mode. Pressing on this switch while in Manual Mode operates the actuator in the close direction. Switch has no function outside of manual mode.

### 4.5.5 Enter Switch

Used to operate the actuator while in Manual Mode. Pressing on this switch while in Manual Mode brakes the actuator if it is currently operating. Switch has no function outside of manual mode.

## 5.0 EtherNet/IP Interface

This section is intended as a reference for configuring and using the EtherNet/IP ports on the Servo NXT EIP. For those unfamiliar with EtherNet/IP, below are a list of references that go into significantly more detail on the concerns and requirements for successfully establishing and managing a functional EtherNet/IP network. This list is not exhaustive, and there are many more references available online if required.

- EtherNet/IP Media Planning & Installation Manual – Pub 148
- EtherNet/IP Network Infrastructure Guide - Pub 35
- Securing EtherNet/IP Networks - Pub 269

## 5.1 EtherNet/IP Conformance

The Servo NXT EIP has been tested at the ODVA headquarters in Ann Arbor, MI, and has been certified conformant to EtherNet/IP standards. For all certified products, the ODVA issues a Declaration of Conformance, and a copy of this document for the Servo NXT EIP is available on request.

It should be established before a network is commissioned that all devices are conformant to ensure communication quality is maintained. However, even when using conformant devices, it still falls on the network designer to maintain good practice in system level design. The included ODVA references should be strictly adhered to, and ideally, any EtherNet/IP network should be inspected and qualified by a third-party.

## 5.2 Scanner Configuration

Before the Servo NXT EIP can be added to an active network, the scanner needs to be configured to recognize it. This can be accomplished by uploading the EDS file for the Servo NXT EIP to the scanner, which can be found on the bray website, [www.bray.com](http://www.bray.com), or can be provided on request.

## 5.3 Address Assignment

Every adapter added to an EtherNet/IP network must have an IP address. The Servo NXT EIP is by default in DHCP mode, where an IP address can be provided to it by a DHCP Server. When the Servo NXT EIP is connected to a network, it

will automatically attempt to gain a lease for an available IP address.

If the Servo NXT EIP is going to be connected to a network that uses static addressing, then a scanner will have to be connected to the Servo NXT EIP to adjust the default settings of the TCP/IP object to make the device use the address stored in memory and, if necessary, change the address to one conformant to the network's requirements.

### 5.4 Establish Connection

Once an IP address has been assigned to the Servo NXT EIP, a Class 3 explicit connection can be established that allows for class and instance attribute data to be read and written. An explicit connection has the benefit of being reliable and connection oriented where every message sent is verified. However, there is a significant amount of overhead associated with requiring every message to be verified. Explicit messaging is used for establishing implicit message generation, but once this is accomplished, it should be used sparingly to reduce the occurrence of collisions.

Once a Class 3 connection has been established with the Servo NXT EIP, Class 1 implicit messages should be configured based on the Connection Manager attributes defined in the EDS file. The EDS file provides limits for implicit messaging to ensure the device maintains reliable generation of data. Since implicit messaging is connectionless, there is no need to establish,

maintain, or terminate a session. Once message generation is started, it continues based on the RPI defined by the scanner, and it does not require the presence of the scanner to occur.

The implicit data generated from the Servo NXT EIP originates from the Assembly Object data attributes. There are three Assembly Objects available:

- Input Assembly – Servo NXT EIP data array that is generated for consumption by the network scanner, containing data relevant to the device's current operation, such as feedback position.
- Output Assembly – Data array sent to the Servo NXT EIP to affect its operation, containing data that changes how the device is operating, such as command position.
- Configuration Assembly – Data array sent to the Servo NXT EIP that defines the operating conditions and limits of the device. This array is only sent at the initiation of an implicit connection and can therefore not be changed once messaging starts unless message generation is halted.

Since Assembly data is application specific, the following sections contain detailed information on the Assembly Object data present in the Servo NXT EIP.

### 5.4.1 Input Assembly Data

<b>Input Assembly Data</b>					
<b>Variable</b>	<b>Data Type</b>	<b>Size (bits)</b>	<b>Notes</b>	<b>Start Bit</b>	<b>Start Byte</b>
Feedback Position	REAL	32	Feedback position from S70 potentiometer. Range: 0-100% (0-90°)	0	0
Motor Current	REAL	32	Current measured from the actuator motor. Range: 0-5.0 A	0	4
Control deviation	REAL	32	Difference between command position and feedback position. Range: 0-100%, (0-90°)	0	8
Close Calibration Offset	REAL	32	Offset between the closed limit switch and the feedback travel limit. Determined during autocalibration. Range: 0-100%, (0-90°)	0	12
Open Calibration Offset	REAL	32	Offset between the open limit switch and the feedback travel limit. Determined during autocalibration. Range: 0-100%, (0-90°)	0	16
Response time	REAL	32	Time in seconds from change of command position to initial change in feedback position (positive values only)	0	20
Stroke Time	REAL	32	Time in seconds the last full stroke took to complete (positive values only)	0	24
Motor Operating Time	REAL	32	Time in hours that the motor has been running (positive values only)	0	28
Energized Time	REAL	32	Time in hours that the Servo has been powered (positive values only)	0	32
PST* Open Time - Initial	REAL	32	Time in seconds to complete open direction travel during the initial partial stroke test	0	36
PST* Close Time - Initial	REAL	32	Time in seconds to complete close direction travel during the initial partial stroke test	0	40
PST* Open Time - Last	REAL	32	Time in seconds to complete open direction travel during the last partial stroke test	0	44
PST* Close Time - Last	REAL	32	Time in seconds to complete close direction travel during the last partial stroke test	0	48
Direction changes	DINT	32	Number of times actuator moves in the opposite direction of its previously commanded direction of travel (positive values only)	0	52
Full strokes	DINT	32	Number of full strokes completed (positive values only)	0	56

<b>Input Assembly Data</b>					
<b>Variable</b>	<b>Data Type</b>	<b>Size (bits)</b>	<b>Notes</b>	<b>Start Bit</b>	<b>Start Byte</b>
Open Limit Switch State	BOOL	1	Set high if the open limit switch has been reached	0	60
Close Limit Switch State	BOOL	1	Set high if the close limit switch has been reached	1	
Open Torque Switch State	BOOL	1	Set high if the open direction overtorque switch has been engaged	2	
Close Torque Switch State	BOOL	1	Set high if the close direction overtorque switch has been engaged	3	
Actuator Stopped	BOOL	1	Set high when the actuator has reached a setpoint	4	
Actuator Closing	BOOL	1	Set high when actuator operating in the closed direction	5	
Actuator Opening	BOOL	1	Set high when actuator operating in the open direction	6	
Autocalibration Running	BOOL	1	Set high when actuator is running through the calibration routine	7	
PST* Running	BOOL	1	Set high when actuator is running through the partial stroke test routine	0	61
Local Mode	BOOL	1	Set high when local control box is determining the travel setpoint	1	
Local Open	BOOL	1	Set high when open command state set at control box	2	
Local Close	BOOL	1	Set high when close command state set at control box	3	
Manual Mode	BOOL	1	Set high when operator at controller is determining the travel setpoint using the controller push buttons.	4	
Manual Open	BOOL	1	Set high when the open push button has been pressed while in manual mode.	5	
Manual Close	BOOL	1	Set high when the close push button has been pressed while in manual mode.	6	
Handwheel Turned	BOOL	1	If acuator position changed while handwheel is engaged, bit turned high until handwheel is disengaged and command position has been reached	7	

<b>Input Assembly Data</b>					
<b>Variable</b>	<b>Data Type</b>	<b>Size (bits)</b>	<b>Notes</b>	<b>Start Bit</b>	<b>Start Byte</b>
Handwheel Fault	BOOL	1	Static Fault Set high when HW (handwheel) pulled	0	62
Feedback Fault	BOOL	1	Static Fault Set high when outside allowed feedback pot range	1	
Limit Switch Fault	BOOL	1	Static Fault Set high when both limit switches engaged	2	
Overtorque Fault	BOOL	1	Static Fault Set high when the actuator attempts to operate a load outside the operational torque limits	3	
Motor Stall Fault	BOOL	1	Dynamic Fault Set high in the event of motor stall (no motor movement detected)	5	
Autocalibration Fault	BOOL	1	Dynamic Fault Set high if autocalibration is unable to complete	6	
Fault Active	BOOL	1	Set high if any fault is active	7	
Calibration Result	BOOL	1	Indicates result of last autocalibration. Set high when device has been successfully calibrated.	0	63
PST* Result	BOOL	1	Indicates result of last partial stroke test. Set high when test completes successfully: PST Last Time is within the allowable deviation of PST Initial Time	1	
Total Byte Length					64



### 5.4.2 Output Assembly Data

Output Assembly Data					
Variable	Data Type	Size (bits)	Notes	Start Bit	Start Byte
Command Position	REAL	32	Customer position setpoint. Range: 0-100% (0-90°)	0	0
Autocalibration Start	BOOL	1	Toggle Bit Change bit state to start internal autocalibration routine. Operates the actuator to the open and close positions to determine the open and close offsets. Adjusts the Feedback Position range to account for these offsets.	0	4
Autocalibration Stop	BOOL	1	Toggle Bit Change bit state to cancel an active autocalibration. If autocalibration is not running, this bit change is ignored.	1	4
Partial Stroke Test Start	BOOL	1	Toggle Bit Change bit state to operate the actuator to PST offset position to test device operability.	2	4
Partial Stroke Test Stop	BOOL	1	Toggle Bit Change bit state to cancel an ongoing partial stroke test. If no test is running, this bit change is ignored.	3	4
Manual Mode On	BOOL	1	Toggle Bit Change bit state to put the controller into manual mode. If controller is already in manual mode, this bit change is ignored.	4	4
Manual Mode Off	BOOL	1	Toggle Bit Change bit state to take the controller out of manual mode. If controller is not in manual mode, this bit change is ignored.	5	4
Clear PST Times	BOOL	1	Toggle Bit Change bit state to clear stored PST times. If no PST times are stored, this bit change is ignored.	6	4
Clear Dynamic Faults	BOOL	1	Toggle Bit Change bit state to disable any faults labelled as dynamic. If no dynamic faults are active, this bit change is ignored.	7	4
Total Byte Length					8

### 5.4.3 Configuration Assembly Data

Configuration Assembly Data					
Variable	Data Type	Size (bits)	Notes	Start Bit	Start Byte
Failure Return Position	REAL	32	Position actuator operates to in the event of loss of Class 1 communication timeout. Range: 0-100% (0-90°) Default: 0% (0°)	0	0
PST* offset position	REAL	32	Offset from current position that the actuator needs to travel during partial stroke testing. Range: 0.5-50% (0.5-50°) Default: 5% (5°)	0	4
PST* allowable deviation	REAL	32	Maximum error allowed between PST Initial Time and PST Last Time Range: 0.5-50% (0.5-50°) Default: 10% (10°)	0	8
Deadband	REAL	32	Allowable offset from position. Range: 0.5-10% (0.5-10°) Default: 1% (1°)	0	12
Set Open Speed	REAL	32	Percent of max speed the motor should run at in the open direction. Range: 10-100% Default: 100%	0	16
Open Speed Start Position	REAL	32	Position where open speed limiting should begin Range: 0-100% (0-90°) Default: 0% (0°)	0	20
Open Speed End Position	REAL	32	Position where open speed limiting should end Range: 0-100% (0-90°) Default: 100% (90°)	0	24
Set Close Speed	REAL	32	Percent of max speed the motor should run at in the close direction. Range: 10-100% Default: 100%	0	28
Close Speed Start Position	REAL	32	Position where close speed limiting should begin Range: 0-100% (0-90°) Default: 100% (90°)	0	32
Close Speed End Position	REAL	32	Position where close speed limiting should end Range: 0-100% (0-90°) Default: 0% (0°)	0	36
Reverse Delay	REAL	32	Time motor delays before reversing direction Range: 1-10s Default: 1s	0	40
Command Resolution	INT	16	Adjustable resolution range for output command position 0: 12-bit (Default) 1: 10-bit 2: 8-bit 3: 6-bit		44

<b>Configuration Assembly Data</b>					
<b>Variable</b>	<b>Data Type</b>	<b>Size (bits)</b>	<b>Notes</b>	<b>Start Bit</b>	<b>Start Byte</b>
Feedback Resolution	INT	16	Adjustable resolution range for input feedback position 0: 12-bit (Default) 1: 10-bit 2: 8-bit 3: 6-bit		46
Reverse Command	BOOL	1	When high, inverts output command position range Default: Low	0	48
Reverse Feedback	BOOL	1	When high, inverts input feedback position range Default: Low	1	
Enable Actuator Speed Limiting	BOOL	1	Set high to enable speed limiting for the range specified Default: Low	2	
Enable Torque Limiting	BOOL	1	Set high to enable torque limit switch detection Default: Low	3	
Enable Motor Stall Detection	BOOL	1	Set high to enable motor stall detection Default: Low	4	
Enable Failure Return	BOOL	1	Set high to have actuator operate to Failure Return Position upon loss of communication Default: Low	5	
Unit: Position	BOOL	1	Low: %, High: ° Default: %	6	
Unit: Temperature	BOOL	1	Low: °C, High: °F Default: °C	7	
Total Byte Length					52

## 6.0 Quick Start Guide

1. Upload the EDS file for the Servo NXT EIP into the scanner that will be establishing the network connection.
2. Connect the Servo NXT EIP to the EtherNet/IP network through the M12 connector.
3. Assign the Servo NXT EIP an IP address through the DHCP server.
  - a. Alternatively, assign an address to the Servo NXT EIP through the TCP/IP object and set it to use the address set in memory.
4. Establish that explicit messages can be exchanged with the Servo NXT EIP through the network scanner.
  - a. Data received should align with the information contained in the EDS file. E.g. Identity Object class and instance attributes
5. Establish an implicit connection with the Servo NXT EIP using the Connection Manager attributes defined in the EDS file.
  - a. The Assembly object data attributes for the configuration array should be defined before the connection is established, as they can only be changed before the connection is established. Otherwise, the default values in the EDS file will be used.

## 7.0 Technical Specifications

<b>Mechanical</b>	
Electronics Enclosure Material	PC/ABS Blend
Mounting Screw Material	Nylon
Terminals	
Wire Gauge	26-16 AWG [0.13-1.31 mm <sup>2</sup> ]
Torque Limit	3.5 in-lbs [15.6 N]
Voltage Limit	200 V
Current Limit	5 A
Switch Force	0.79 lbf [3.5 N]
Temperature Rating	-25 to 65°C
Installation	Designed for use within Bray actuators

<b>Electrical</b>	
Input Voltage	120VAC ± 10% 230VAC ± 10% 24VAC ± 10% 24VAC ± 10%
Motor Current, max	5 A



BRAY FLOW CONTROL SOLUTIONS ARE AVAILABLE FOR A VARIETY OF INDUSTRIES.

**ENERGY**

Mining  
Oil & Gas  
Power / FGD  
Nuclear Power

**WATER**

Water / Wastewater  
Ultra Pure Water  
Desalination  
Irrigation

**INDUSTRIAL**

Chemical  
Pulp & Paper  
Textile  
Marine

**INFRASTRUCTURE**

Beverage & Food  
Transportation  
Heating, Ventilation & Air Conditioning (HVAC)



**US HEADQUARTERS**

**Bray International, Inc.**  
13333 Westland East Blvd.  
Houston, Texas 77041  
Tel: 281.894.5454

**CHINA HEADQUARTERS**

**Bray Controls (ZheJiang) Co. Limited**  
98 GaoXin # 6 Road  
XiaoShan Economic & Development Zone  
HangZhou, ZheJiang 311231, P.R. China  
Tel: 86 571 8285 2200

**EUROPE HEADQUARTERS**

**Bray Armaturen & Antriebe Europa**  
Halskestraße 25  
47877 Willich  
Germany  
Tel: +49 2154 8875-0

**INDIA HEADQUARTERS**

**Bray Controls India Pvt. Ltd.**  
Plot No. H-18 & H-19  
SIPCOT Industrial Park  
Vallam Vadagal, Echoor Post  
Sriperumbudur Taluk  
Kancheepuram District  
Tamil Nadu - 631 604  
Tel: +91-44-6710100



THE SMART CHOICE FOR FLOW CONTROL SINCE 1986.  
WITH MORE THAN 300 LOCATIONS WORLDWIDE,  
FIND A REPRESENTATIVE NEAR YOU AT **BRAY.COM**

All statements, technical information, and recommendations in this bulletin are for general use only. Consult Bray representatives or factory for the specific requirements and material selection for your intended application. The right to change or modify product design or product without prior notice is reserved. Patents issued and applied for worldwide.