# SERIES 98H HYDRAULIC SCOTCH YOKE ACTUATOR

## SIL SAFETY MANUAL







THE HIGH PERFORMANCE COMPANY

## Contents

| Introduction                                | 3   |
|---|---|
| Terms and Abbreviations                     | 3   |
| Acronyms                                    | 4   |
| Product Support                             | 4   |
| Device Description                          | 5   |
| Designing a SIL Using A Series 98H Actuator | 5   |
| Installation and Commissioning              | 7   |
| Operation and Maintenance                   | 8   |
|   | Terms and AbbreviationsAcronymsProduct SupportDevice DescriptionDesigning a SIL Using A Series 98H ActuatorInstallation and Commissioning |

## 1.0 INTRODUCTION

1.1 This Safety Manual provides information necessary to design, install, verify and maintain a Safety Instrumented Function (SIF) using Bray's Series 98H Hydraulic Scotch Yoke Actuator. This manual provides necessary requirements for meeting the IEC 61508 or IEC 61511 functional safety standards.

## 2.0 TERMS AND ABBREVIATIONS

- 2.1 Safety: Freedom from unacceptable risk of harm
- 2.2 **Functional Safety:** The ability of a system to carry out the actions necessary to achieve or to maintain a defined safe state for the equipment / machinery / plant / apparatus under control of the system
- 2.3 **Basic Safety:** The equipment must be designed and manufactured such that it protects against risk of damage to persons by electrical shock and other hazards and against resulting fire and explosion. The protection must be effective under all conditions of the nominal operation and under single fault condition
- 2.4 **Safety Assessment:** The investigation to arrive at a judgment based on evidence of the safety achieved by safety-related systems
- 2.5 **Fail-Safe State Spring Return:** State where hold position hydraulic pressure is released and the spring is extended
- 2.6 **Fail-Safe State Double Acting:** State where the hold position pressure is released and pressure is supplied to the trip side of the actuator
- 2.7 **Fail Safe:** Failure that causes the device to go to the defined fail-safe state without a demand from the process.
- 2.8 **Fail Dangerous:** Failure that prevents the actuator from rotating with sufficient torque to move a valve to its fail-safe state
- 2.9 **Fail Dangerous Undetected:** Failure that is dangerous and that is not being diagnosed by automatic diagnostics, such as partial valve stroke testing.
- 2.10 **Fail Dangerous Detected:** Failure that is dangerous but is detected by automatic diagnostics, such as partial valve stroke testing.
- 2.11 **No Effect:** Failure of a component that is part of the safety function but that has no effect on the safety function.
- 2.12 **Low Demand Mode:** Mode, where the frequency of demands for operation made on a safety-related system is no greater than twice the proof test frequency



## 3.0 ACRONYMS

- 3.1 **FMEDA:** Failure Modes, Effects and Diagnostic Analysis
- 3.2 HFT: Hardware Fault Tolerance
- 3.3 **Management of Change (MOC):** These are specific procedures often done when performing any work activities in compliance with government regulatory authorities
- 3.4 **PFD**<sub>AVG</sub>: Average Probability of Failure on Demand
- 3.5 **SFF Safe Failure Fraction:** The fraction of the overall failure rate of a device that results in either a safe fault or a diagnosed unsafe fault.
- 3.6 **Safety Instrumented Function (SIF):** A set of equipment intended to reduce the risk due to a specific hazard (a safety loop).
- 3.7 **Safety Integrity Level (SIL):** Discrete level (one out of a possible four) for specifying the safety integrity requirements of the safety functions to be allocated to the E/E/PE safety-related systems where Safety Integrity Level 4 has the highest level of safety integrity and Safety Integrity Level 1 has the lowest.
- 3.8 **Safety Instrumented System (SIS):** Implementation of one or more Safety Instrumented Functions. A SIS is composed of any combination of sensor(s), logic solver(s), and final element(s).

## 4.0 PRODUCT SUPPORT

Please refer to the back cover for your regional Bray office contact details.

#### 4.1 Related Literature - Hardware Documents

- 4.1.1 Series S98 & 98H Scotch Yoke Actuator Installation, Operation and Maintenance Instructions
- 4.1.2 Series 98H Brochure
- 4.1.3 Series 98H Technical Manual

#### 4.2 Guidelines/References

- 4.2.1 Safety Integrity Level Selection Systematic Methods Including Layer of Protection Analysis, ISBN 1-55617-777-1, ISA
- 4.2.2 Control System Safety Evaluation and Reliability, 2nd Edition, ISBN 1-55617-638-8, ISA
- 4.2.3 Safety Instrumented Systems Verification, Practical Probabilistic Calculations, ISBN 1-55617-909-9, ISA

#### 4.3 **Reference Standards**

- 4.3.1 Functional Safety
- 4.3.2 IEC 61508: 2010 Functional safety of electrical/electronic/ programmable electronic safety-related systems
- 4.3.3 IEC 61511 Functional Safety Safety Instrumented Systems for the Process Industry Sector
- 4.3.4 ISO 5211:2017 Industrial Valves- Part Turn actuator attachment.
- 4.3.5 IEC 60529:2013 Degrees of protection provided by enclosures (IP Code)
- 4.3.6 BS EN 15714-4:2009 Hydraulic part-turn actuators for industrial valves. Basic requirements

## 5.0 DEVICE DESCRIPTION

- 5.1 The Series 98H Actuator is a modular-design scotch yoke type quarter turn actuator, to actuate various valve types (ball, plug and butterfly styles) or other elements such as dampers. The scotch yoke actuator renders torque output suitable to the requirement of these styles of valves, wherein the torque to operate is not constant through the stroke of the actuator. The linear stroke of the hydraulic cylinder is converted to rotary motion of the yoke, and the torque output that is higher at the ends of stroke and minimum at mid stroke.
- 5.2 It operates by hydraulic fluid pressure from 500 to 3000 psi (34.5 to 206.8 bar) and the fail-safe direction is field-reversible. The actuators come in two basic configurations, Double Acting and Spring Return. The modular construction of the pressure, torque and the spring modules makes the fail-safe direction easily reversible. The manual overrides and options with accessories cater to the varied requirements of applications.

## 6.0 DESIGNING A SIL USING A SERIES 98H ACTUATOR

#### 6.1 Safety Functions

- 6.1.1 When de-energized, the actuator moves to its fail-safe position. Depending on configuration of the final element, the actuator will rotate the valve plug to close off the flow path through the valve body or open the flow path through the valve body. When using a double acting actuator as part of a SIF the availability of the hydraulic pressure must be included in the reliability analysis.
- 6.1.2 The Series 98H Actuator is intended to be part of final element subsystem as defined per IEC 61508 and the achieved SIL level of the designed function must be verified by the designer.

#### 6.2 Environmental Limits

6.2.1 The designer of a SIF must check that the product is rated for use within the expected environmental limits. Refer to the Series 98H Technical Manual for environmental limits.

#### 6.3 Application Limits

6.3.1 The materials of construction of the actuator are specified in the Series 98H Actuators Brochure and Technical Manual. It is especially important that the designer check for material compatibility considering on-site chemical contaminants and hydraulic fluid supply conditions. If the Actuator is used outside of the application limits or with incompatible materials, the reliability data provided becomes invalid.

#### 6.4 **Design Verification**

- 6.4.1 A Failure Mode, Effects, and Diagnostics Analysis (FMEDA) report details all failure rates and failure modes as well as the expected lifetime
- 6.4.2 The achieved Safety Integrity Level (SIL) of an entire Safety Instrumented Function (SIF) design must be verified by the designer via a calculation of PFDAVG considering architecture, proof test interval, proof test effectiveness, any automatic diagnostics, average repair time and the specific failure rates of all products included in the SIF. Each subsystem must be checked to assure compliance with minimum hardware fault tolerance (HFT) requirements. The exida exSILentia® tool is recommended for this purpose as it contains accurate models for the actuator and its failure rates.
- 6.4.3 When using a Series 98H actuator in a redundant configuration, a common cause factor of 10% should be included in safety integrity calculations unless a lower value can be justified based on site conditions.
- 6.4.4 The failure rate data listed in the FMEDA report is only valid for the useful life time of the actuator. The failure rates will increase sometime after this time period. Reliability calculations based on the data listed in the FMEDA report for mission times beyond the lifetime may yield results that are too optimistic, i.e. the calculated Safety Integrity Level will not be achieved.

#### 6.5 SIL Capability

#### 6.5.1 Systematic Integrity



The product has met manufacturer design process requirements of Safety Integrity Level (SIL) 3. These are intended to achieve sufficient integrity against systematic errors of design by the manufacturer. A Safety Instrumented Function (SIF) designed with this product must not be used

at a SIL level higher than the statement without "prior use" justification by end user or diverse technology redundancy in the design.

6.5.1.1

#### 6.5.2 Random Integrity

6.5.2.1 The Series 98H Actuator is a Type A Device. This Actuator is only one component in the final element. The PFDAVG and SFF must be calculated for the entire final element subsystem. This analysis must account for any hardware fault tolerance and architecture constraints.

#### 6.5.3 Safety Parameters

6.5.3.1 For detailed failure rate information refer to the Failure Modes, Effects and Diagnostic Analysis Report for the Series 98H Actuator.

#### 6.6 Connection of the Series 98H Actuator to the SIS Logic Solver

6.6.1 The Series 98H Actuator is connected to the safety rated logic solver through a control device such as a hydraulic solenoid or valve positioner.

#### 6.7 General Requirements

- 6.7.1 The system's response time shall be less than process safety time as defined in the SIF Safety Requirements Specification. Since the response time of the Series 98H Actuator depends upon the hydraulic pump flowrate, line size, hoses, line pressure, flow constrictors like flow control valves, Cv of the control elements like solenoid valves, their response times, pressure regulators, hydraulic override (on DA models), sandwich gearbox manual override, the response time must be confirmed for each final element assembly. All SIS components including the Series 98H Actuator must be operational before process start-up.
- 6.7.2 The user shall verify that the Series 98H Actuator is suitable for use in safety applications by confirming the actuator's nameplate is properly marked.
- 6.7.3 Personnel performing maintenance and testing on the Series 98H Actuator shall be competent to do so.
- 6.7.4 Results from the proof tests shall be recorded and reviewed periodically. The useful life of the Actuator is discussed in the Failure Modes, Effects and Diagnostic Analysis Report for the Series 98H Actuator.

## 7.0 INSTALLATION AND COMMISSIONING

#### 7.1 Installation

- 7.1.1 The Series 98H Actuator must be installed per standard practices outlined in the Installation Manual.
- 7.1.2 The environment must be checked to verify that environmental conditions do not exceed the rating
- 7.1.3 The Actuator must be accessible for physical inspection

#### 7.2 Physical Location and Placement

- 7.2.1 The Series 98H Actuator shall be accessible with sufficient room for hydraulic connections and shall allow manual proof testing.
- 7.2.2 Hydraulic piping to the actuator shall be kept as short and straight as possible to minimize the fluid flow restrictions. Long or kinked hydraulic tubes may increase the actuation time. The hydraulic return line shall be sufficiently sized, to prevent any back pressure.
- 7.2.3 The Actuator shall be mounted in a low vibration environment. If excessive vibration can be expected special precautions shall be taken to ensure the integrity of hydraulic connectors or the vibration should be reduced using appropriate damping mounts.
- 7.3 Hydraulic Connections

Recommended piping size for the hydraulic connections to the Actuator is the same as the nominal port size. The length of tubing between the Series 98H Actuator and the control device, such as a hydraulic solenoid valve, shall be kept as short as possible and free of kinks.

For S98H hydraulic actuators, operating media shall be the recommended grade of hydraulic fluid, specified to ISO 4406 class 18/16/13 maximum contamination level and flash point > 157°C.

## 8.0 OPERATION AND MAINTENANCE

#### 8.1 Proof Test Without Automatic Testing

- 8.1.1 The objective of proof testing is to detect failures within the Actuator that are not detected by any automatic diagnostics of the system.Of main concern are undetected failures that prevent the safety instrumented function from performing its intended function.
- 8.1.2 The frequency of proof testing, or the proof test interval, is to be determined in reliability calculations for the safety instrumented functions for which a Series 98H Actuator is applied. The proof tests must be performed more frequently than or as frequently as specified in the calculation in order to maintain the required safety integrity of the safety instrumented function.
- 8.1.3 The following proof test is recommended. The results of the proof test should be recorded and any failures that are detected and that compromise functional safety should be reported to Bray Controls. The suggested proof test consists of a full stroke of the valve coupled to the Series 98H Actuator.

## 8.1.4 Table 1 - Suggested Proof Test

| Step | Action  |
|------|---|
| 1.   | Bypass the safety function and take appropriate action to avoid a false     |
|      | trip.   |
| 2.   | Interrupt or change the direction of hydraulic fluid supply to the actuator |
|      | to force the actuator and coupled valve to the Fail-Safe state and confirm  |
|      | that the Safe State was achieved and within the stipulated time.            |
| 3.   | Restore hydraulic fluid supply to the actuator and perform a routine        |
|      | inspection of the actuator for any leaks, visible damage, hydraulic fluid   |
|      | contamination, etc. and confirm that the normal operating state is          |
|      | restored.   |
| 4.   | Remove any bypass to restore normal operation.                              |

8.1.5 Table 3 lists the proof test coverage for various product configurations

#### 8.1.6 Table 2 Proof Test Coverage

| Device                                 | Normal | With PVST |
|--|--------|-----------|
| Series 98H, Spring-Return Actuator, SR | 92%    | 75%       |
| Series 98H, Double Acting Actuator, DA | 94%    | 76%       |
| Series 98H, Double Acting Actuator, DD | 94%    | 77%       |

8.1.7 The person(s) performing the proof test of a Series 98H Actuator should be trained in SIS operations, including bypass procedures, valve maintenance and company Management of Change procedures. No special tools are required.

## 8.2 Proof Test with Automatic Partial Valve Stroke Testing

8.2.1 An automatic partial valve stroke testing scheme that performs a partial stroke of the isolation valves with the Series 98H Actuator and measures valve movement and timing will detect many potentially dangerous failure modes. It is recommended that a physical inspection (Step 3 from Table 1) be performed on a periodic basis with the time interval determined by plant conditions. A maximum inspection interval of five years is recommended.

#### 8.3 Repair and Replacement

8.3.1 Repair procedures in the Series 98H Actuator Installation, Operation and Maintenance manual must be followed.



## 8.4 Useful Life

#### 8.4.1 A major factor influencing the useful life is the air quality.

Based on general field failure data a useful life period of approximately 15 years is expected for the 98H Series Actuator.

For high demand mode applications, the useful lifetime is limited by the number of cycles. The useful lifetime is >10,000 full scale cycles or 8 to 10 years, whichever results in the shortest lifetime.

When site experience indicates a shorter useful lifetime than indicated in this appendix, the number based on site experience should be used.

#### 8.5 Bray Notification

8.5.1 Any failures that are detected and that compromise functional safety should be reported to Bray Controls. In case of failure please refer to the back cover and contact your regional Bray customer service.

#### 8.6 **Product Registration**

8.6.1 If the product is being used in a safety application and there is a desire to receive notices regarding the product, register the product with Bray Controls customer service. SINCE 1986, BRAY HAS PROVIDED FLOW CONTROL SOLUTIONS FOR A VARIETY OF INDUSTRIES AROUND THE WORLD.

VISIT **BRAY.COM** TO LEARN MORE ABOUT BRAY PRODUCTS AND LOCATIONS NEAR YOU.

## **HEADQUARTERS**

**Bray International, Inc.** 13333 Westland East Blvd. Houston, Texas 77041 Tel: +1.281.894.5454



All statements, technical information, and recommendations in this bulletin are for general use only. Consult Bray representatives or factory for the specific requirements and material selection for your intended application. The right to change or modify product design or product without prior notice is reserved. Patents issued and applied for worldwide. Bray® is a registered trademark of Bray International, Inc.

© 2024 BRAY INTERNATIONAL, INC. ALL RIGHTS RESERVED. BRAY.COM

SM-1006\_S98\_Hydaulic 20241209



THE HIGH PERFORMANCE COMPANY

**BRAY.COM**